

# CONNY IP68 QUICK CONNECYOR



<b>EN</b>	Installation Instructions	<b>IT</b>	Istuzioni di montaggio
<b>DE</b>	Montageanleitung	<b>LT</b>	Montavimo Instrukcijos
<b>CZ</b>	Montážní návod	<b>LV</b>	Instalācijas instrukcija
<b>DK</b>	Monteringsvejledning	<b>NO</b>	Monteringsanvisning
<b>EE</b>	Paigaldusjuhend	<b>PL</b>	Instrukcja montażu
<b>FI</b>	Asennusohje	<b>SE</b>	Installationsanvisning
<b>FR</b>	Notice de montage	<b>RU</b>	Инструкция по монтажу
<b>HU</b>	Szerelési útmutató	<b>SRB</b>	Instrukcija za instalaciju
<b>HR</b>	Uputstvo za montažu	<b>SK</b>	Montážny návod
<b>NL</b>	Montagehandleiding	<b>SLO</b>	Navodilo za montažo
<b>RO</b>	Instructiuni de montaj	<b>CN</b>	安装说明书

### NOTE

- This component may only be installed, operated or maintained by qualified personnel.
- Operating personnel must have read and understood these instructions.
- Related technical information is available at: [www.wieland-electric.com](http://www.wieland-electric.com)

### CAUTION

- A locking device is required for DIN EN 61535 approval. IEC 61535 conformity does not automatically exclude the danger of confusion with installation plug connector systems from the same manufacturer!
- Installation plug connector systems are no substitute for national plug/outlet systems for domestic use.
- To maintain the IP- and NEMA-rating type of enclosure, protective caps (accessory) must be mounted on all unoccupied connectors!
- The connectors must not be exposed to bending forces (e.g. do not attach loads to the cable, no free-dangling cable windings etc.).
- Observe the country-specific regulations for installation.
- The connectors are not suitable for current interrupting. Never connect or disconnect under load!

### WARNING

When using connectors with contact sealing, use only one connector with contact sealing – either male or female connector.

#### Bemessungsdaten / Rated values

Bemessungsstrom / Rated current	16A
---------------------------------	-----

